




NIKON D700 1/200 f/11



NIKON D700 1/250 f/11



NIKON D700 1/320 f/11



NIKON D700 1/400 f/11



NIKON D700 1/500 f/11



NIKON D700 1/640 f/11




NIKON D700 1/800 f/11




NIKON D700 1/1000 f/11




NIKON D700 1/1250 f/11




NIKON D700 1/1600 f/11



NIKON D700 1/2000 f/11



NIKON D700 1/2500 f/11



NIKON D700 1/3200 f/11



NIKON D700 1/4000 f/11



NIKON D700 1/5000 f/11




NIKON D700 1/6400 f/11




NIKON D700 1/8000 f/11


D700, AB1600, +3
HyperSync Only Disabled, Highest Energy




NIKON D700 1/200 f/11



NIKON D700 1/250 f/11




NIKON D700 1/320 f/11




NIKON D700 1/400 f/11




NIKON D700 1/500 f/11




NIKON D700 1/640 f/11



NIKON D700 1/800 f/11



NIKON D700 1/1000 f/11




NIKON D700 1/1250 f/11




NIKON D700 1/1600 f/11



NIKON D700 1/2000 f/11




NIKON D700 1/2500 f/11




NIKON D700 1/3200 f/11



NIKON D700 1/4000 f/11



NIKON D700 1/5000 f/11




NIKON D700 1/6400 f/11




NIKON D700 1/8000 f/11


D700, AB1600, +2
HyperSync Only Disabled, Highest Energy




NIKON D700 1/200 f/11




NIKON D700 1/250 f/11




NIKON D700 1/320 f/11




NIKON D700 1/400 f/11



NIKON D700 1/500 f/11



NIKON D700 1/640 f/11



NIKON D700 1/800 f/11




NIKON D700 1/1000 f/11




NIKON D700 1/1250 f/11




NIKON D700 1/1600 f/11




NIKON D700 1/2000 f/11




NIKON D700 1/2500 f/11



NIKON D700 1/3200 f/11




NIKON D700 1/4000 f/11



NIKON D700 1/5000 f/11




NIKON D700 1/6400 f/11




NIKON D700 1/8000 f/11


D700, AB1600, +1
HyperSync Only Disabled, Highest Energy




NIKON D700 1/200 f/11



NIKON D700 1/250 f/11




NIKON D700 1/320 f/11




NIKON D700 1/400 f/11




NIKON D700 1/500 f/11




NIKON D700 1/640 f/11




NIKON D700 1/800 f/11




NIKON D700 1/1000 f/11




NIKON D700 1/1250 f/11




NIKON D700 1/1600 f/11




NIKON D700 1/2000 f/11




NIKON D700 1/2500 f/11



NIKON D700 1/3200 f/11




NIKON D700 1/4000 f/11



NIKON D700 1/5000 f/11




NIKON D700 1/6400 f/11




NIKON D700 1/8000 f/11


D700, AB1600, +0
HyperSync Only Disabled, Highest Energy




NIKON D700 1/200 f/11




NIKON D700 1/250 f/11




NIKON D700 1/320 f/11




NIKON D700 1/400 f/11




NIKON D700 1/500 f/11




NIKON D700 1/640 f/11




NIKON D700 1/800 f/11




NIKON D700 1/1000 f/11




NIKON D700 1/1250 f/11




NIKON D700 1/1600 f/11




NIKON D700 1/2000 f/11




NIKON D700 1/2500 f/11




NIKON D700 1/3200 f/11




NIKON D700 1/4000 f/11



NIKON D700 1/5000 f/11




NIKON D700 1/6400 f/11




NIKON D700 1/8000 f/11


D700, AB1600, -1
HyperSync Only Disabled, Highest Energy




NIKON D700 1/200 f/11




NIKON D700 1/250 f/11




NIKON D700 1/320 f/11




NIKON D700 1/400 f/11




NIKON D700 1/500 f/11




NIKON D700 1/640 f/11




NIKON D700 1/800 f/11




NIKON D700 1/1000 f/11




NIKON D700 1/1250 f/11




NIKON D700 1/1600 f/11




NIKON D700 1/2000 f/11




NIKON D700 1/2500 f/11




NIKON D700 1/3200 f/11




NIKON D700 1/4000 f/11



NIKON D700 1/5000 f/11




NIKON D700 1/6400 f/11




NIKON D700 1/8000 f/11


D700, AB1600, -2
HyperSync Only Disabled, Highest Energy




NIKON D700 1/200 f/11




NIKON D700 1/250 f/11




NIKON D700 1/320 f/11




NIKON D700 1/400 f/11




NIKON D700 1/500 f/11



NIKON D700 1/640 f/11




NIKON D700 1/800 f/11



NIKON D700 1/1000 f/11




NIKON D700 1/1250 f/11




NIKON D700 1/1600 f/11




NIKON D700 1/2000 f/11




NIKON D700 1/2500 f/11




NIKON D700 1/3200 f/11




NIKON D700 1/4000 f/11



NIKON D700 1/5000 f/11



NIKON D700 1/6400 f/11



NIKON D700 1/8000 f/11

D700, AB1600, -3
HyperSync Only Disabled, Highest Energy